

HOW THE MODES WORK

Semi: single trigger pull = single shot

TA-Ramp: ramp begins after 3rd trigger pull

B-Ramp: Pull and hold trigger = 2 balls, pull and release = 3 balls, ramp is activated on the first trigger pull. Must pull and release trigger at a rate of 4+ pulls per second.

Full Auto: 4 quick trigger pulls and hold on the 4th

MODE	BPS	LED FLASH	SWITCH 1	SWITCH 2
Semi	18	green	off	off
TA-Ramp	15	yellow	on	on
B-Ramp	18	red	off	on
Full Auto	15	green-yellow-red	on	off

**FOR MORE INFORMATION ON THE OPERATION OF YOUR MARKER,
CONSULT YOUR OWNERS MANUAL.**

